


# BANRACK-88, +, L, and XL - Banner Rack Setup

	Minimum		Maximum	
	Width	Height	Width	Height
BANRACK-88	48"	36"	96"	96"
BANRACK-+	60"	36"	120"	96"
BANRACK-L	72"	48"	144"	96"
BANRACK-XL	72"	48"	144"	120"

**\*Banner Assembly:**

**Pole Pockets** are commonly used on the top and bottom and must have a **minimum diameter of 1.75"**



1. Attach both Feet to the bottom of the Upright Poles with the Foot Bolts and included tool.



2. Telescope the Upright Poles up at least 6" to open the bottom hole in the pole.



3. Connect the 2-part Horizontal Poles with the aluminum connectors.

**NOTE: BANRACK-L & XL connect with a bolt and BANRACK-88 skips this step with a 1-part pole**



4. If the banner has pole pockets then slide it onto the poles now. Use the Thumbscrews to bolt the Horizontal poles to the Upright Poles.

5. Telescope the poles out to the correct size. The Feet should be perpendicular to the frame.



**\*For Indoor Use Only**